



Use the calculation tool to calculate how much you should cut off the tunnel



Cut off the panels



Install the inner flap in the top panel



Install the panels in the aluminum profiles ...



... with glue in the profiles of the panels



Secure with the screws and let the glue dry



Install in the wall and finish with the frame